



Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 11-

Priming Cover Strip Tape for Continuation to the Next Roll

	<p><u>Step 1-</u> Ensure the liner is dry and free of mud or other contaminants.</p>
	<p><u>Step 2-</u> Prime the final 2"-4" of Cover Strip Tape and overlap the second roll of this tape to the edge of the primed area.</p>
	<p><u>Step 3-</u> Roll the tapes to mate them together.</p> <p>A similar methodology can be used when continuing on with 3" Splice Tape</p>

This Detail featured these Firestone Specialty Products:

Item

- PondGard EPDM Rubber Membrane
- QuickPrime Plus Primer
- QuickScrubber
- 6" QuickSeam Cover Strip tape

Part Number(s)

Varies by Size
W563587041 or W563587044
W563582045
W56RAC1693 or W56RAC1616