






Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 15- Fitting PondGard Panels Around Pipes

	<p><u>Step 1-</u> Cut a hole in the PondGard panel that is approximately 75% the outside diameter of the pipe protruding from the substrate.</p>
	<p><u>Step 2-</u> Slide the PondGard into place over the base of the pipe.</p> <p style="text-align: center;">(Steps 3 & 4 Continued Below)</p>

In the event you can not move the PondGard panel

	<p><u>Sub Step 1-</u> Cut the panel to expose the pipe.</p>
	<p><u>Sub Step 2-</u> Cut a target patch with a properly sized hole and place it over the pipe.</p>
	<p><u>Sub Step 3-</u> Ensure the liner is dry and free of mud or other contaminants.</p>

Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 15 (continued)-

Fitting PondGard Panels Around Pipes



Sub Step 4- Seam the target patch to the PondGard panel with primer and either 6" QuickSeam Cover Strip or QuickSeam Splice Tape (See either Detail 9- Creating A Seam With 6" QuickSeam Cover Strip Tape or Detail 10- Creating A Seam With 3" QuickSeam Splice Tape).



Step 3- Once the PondGard is properly positioned over the pipe adhere a piece of QuickSeam FormFlash to the pipe.

Step 4- Roll the flashing to insure adhesion to the pipe.

This Detail featured these Firestone Specialty Products:

Item

- PondGard EPDM Rubber Membrane
- QuickPrime Plus Primer
- QuickScrubber
- Hand roller

Part Number(s)

Varies by Size
W563587041 or W563587044
W563582045
W563582023